



REPLACEMENT SHEET

FIG. 1

System Architecture






FIG. 2



REPLACEMENT SHEET

FIG. 3

FOOT INTERFACE
& RELATED SENSORS



REPLACEMENT SHEET

FIG. 4A
THE ENTIRE SKIN SURFACE





FIG. 4B
HEAD, SHOULDERS, CHEST, BACK,
TORSO AND ARMS



REPLACEMENT SHEET

FIG. 4C
HEAD, SHOULDERS, CHEST, BACK
AND ARMS





FIG. 4D
HEAD, SHOULDERS, CHEST AND BACK



REPLACEMENT SHEET

FIG. 4E
SHOULDERS, CHEST, BACK
AND ARMS





FIG. 4F
SHOULDERS, CHEST, BACK AND TORSO



REPLACEMENT SHEET

FIG. 4H
TORSO AND LEGS






FIG. 4G
CHEST, BACK, TORSO AND LEGS



REPLACEMENT SHEET

FIG. 5


Control Algorithm - Cooling



REPLACEMENT SHEET

FIG. 6

$T_{\text{Interface}}$ affects Vasoconstriction & Vasodilation



$$\Delta T = \text{Temperature Gradient} \equiv |T_{\text{Core}} - T_{\text{Interface}}|$$


is the Driving Force in: Heat Transfer
 at the
 Thermal Interface

- Cooling: $T_{\text{Interface}} < T_{\text{Core}}$
- Warming: $T_{\text{Interface}} > T_{\text{Core}}$

REPLACEMENT SHEET

FIG. 7

$T_{\text{Interface}}$ affects Vasoconstriction & Vasodilation
(as measured by Blood Flow)



For each individual,

- Vasoconstriction [VC] occurs below a certain Temp range
- Vasoconstriction [VD] occurs above that Temp range


Blood Flow can be measured by:

- Laser Doppler
- Bio-Impedance
- Light Absorbption (Pulse Oximetry)

REPLACEMENT SHEET

FIG. 8

Heat Transfer = f (Temp Grad x Blood Flow)
Figure shows Temp Grad & Blood Flow vs. $T_{\text{Interface}}$ superimposed




Maximum Heat Transfer
occurs @

The lowest $T_{\text{Interface}}$ where
Vasodilation occurs

REPLACEMENT SHEET

FIG. 9

Hysteresis:



The transition between Vasoconstriction and Vasodilation is

NOT Identically Reversible...

The transition occurs at a different temperature range depending on the initial condition

Typically, the transition from:

VC \longrightarrow VD


occurs at a $T_{\text{Interface}}$ range above

VD \longrightarrow VC

REPLACEMENT SHEET

FIG. 10

If Vasodilation is initially detected




- (A) Blood Flow Sensor detects VD, $T_{\text{Interface}} = T_{\text{set}}$
- (B) System controller decreases $T_{\text{Interface}}$ until VC detected
- (C) $T_{\text{Interface}}$ increases above transition temp range, VD occurs
- (D) System controller decreases $T_{\text{Interface}}$ to $T_{\text{Max Heat Transfer}}$

$$T_{\text{Max Heat Transfer}} < T_{\text{set}}$$

REPLACEMENT SHEET

FIG. 11

If Vasoconstriction is initially detected



- (A) Blood Flow Sensor detects VC, $T_{\text{Interface}} = T_{\text{set}}$
- (B) System controller increases $T_{\text{Interface}}$
- (C) $T_{\text{Interface}}$ increases above transition temp range, VD occurs
- (D) System controller decreases $T_{\text{Interface}}$ to $T_{\text{Max Heat Transfer}}$

$$T_{\text{Max Heat Transfer}} > T_{\text{set}}$$